

# Shanling USB Driver

Driver is only need for Windows system and only when device is used in USB DAC mode.  
Mac and Linux systems works without any need of driver.

There is no need to install driver for simple file transfer over USB.

## Compatible with:

Shanling M0

Shanling Q1

Shanling M2X

Shanling M5s

Shanling M6 & M6 Pro

*\*Shanling UP2 and UP4 work without drivers.*

## How to install:

1. Have your Shanling device ready and make sure it's set to USB DAC mode.
2. Run "setup.exe" software and follow instructions in the software.
3. After installation is successful, switch to "Shanling Audio Device" in sound settings of your computer.